nextbook™ FAQ

EFUN™

Answers for some of your questions are available online at www.nextbookusa.com (http://nextbookusa.com/faqs_new.asp)

STEP 1

Setting up Wi-Fi

1. **Press Wi-Fi from main menu**
2. **Click on "Wi-Fi" to turn on connection**
3. **Once Wi-Fi connection is on, click on "Wi-Fi Settings"**
4. **Select your Wi-Fi network. Type in Password if necessary**
5. **Your Ebook Reader is connected to Wi-Fi.**

STEP 2

Setting up Adobe ID

I. Make sure Wi-Fi connection is ON
II. Register Adobe ID for free
To register for a free Adobe ID, you can choose from the following methods:

Method A

Simply tap on Borders Icon on your Nextbook – follow step by step to register the account for free on nextbook

Method B

Register the FREE account on PC/MAC computer
https://www.adobe.com/cfusion/membership/



Once you have completed registration, go back to Nextbook and login

STEP 3

Setting up Borders Account

I. Make sure Wi-Fi connection is ON
II. Register Borders Account for free
Note: You will need to login to Borders Ebook Store with your Adobe ID. You only need to login once.
To register for a free Borders account, you can choose from the following methods:

Method A

- Simply tap on the borders icon on your Nextbook. The unit will ask you to enter your Adobe ID to "authorize your device". Enter your username and logon as registered with Adobe (From Step 2). Then follow the on-screen instructions to setup your borders.com account.

Method B (Preferred Method)

Register the FREE account on PC/MAC computer
https://www.borders.com/online/store/LogonForm



Once you have completed registration, login from your PC/MAC
- Create/Update Quick Checkout Profile and follow the steps to enter your credit card info to help to speed up the ebook buying process on Nextbook



- Go back to Nextbook and login using your Borders ID and Password

Still having trouble? Please give us a call at
Toll Free Number: ***1-888-415-5177***
Our hours of operation are ***Monday - Friday, 8am to 5pm PST (Pacific Standard Time)***